
Power Source
Charging
1
2
3
4
ACC
IG1
AM1
AM2
IG2
ST2
I10
Ignition SW
W
B
B–Y
B–W
IF
IM
25A
AM1
15A
AM2
IB
IA4
B–R
1D
1B
1C
1A
100A ALT
5A ALT–S
30A MAIN
B–G
FL MAIN
2. 0L
Battery
IL
IK
B–O
C 9
Combination Meter
Charge
Daytime Running Light
Relay<4–2>
3B
Y
EA1
II2
G 1(A), G 2(B)
Generator
10A
GAUGE
IA
IG1
Relay
IG
IH
R–W
J 4(A), J 5(B)
Junction
Connector
W–B
J 6
Junction
Connector
J 7
Junction
Connector
Behind the Combination
Meter
IE
Right
Kick
Panel
IG

(Cont. next page)